

### 3. LCD display instruction

LCD(94774) shows: Speed, Time, Distance, Calories.

### 4. Button function

- Function button: Speed Shortcuts 4 (3, 6, 9, 12)
  - “Start” button      “Stop” button
  - “Program” button      “Mode” button
  - “Speed+” button      “Speed-” button

### 5. Button function and operation

“Start” button - Start the motor

“Stop” button - Stop the motor

“Program” button - Auto program selection

“Mode” button - Countdown mode selection

“Speed+/-” button - Adjust speed when running, adjust parameter value when setting


“Speed Shortcuts” - Directly select speed value when running

### 6. Sport modes

#### A. Manual mode

Enter manual mode: After the electronic power meter-wide display, enter the initial standby mode, then press the start button, enter to manual mode.

Electronic Watch Assembly: the First Electronic Watch is folded up against the column and used to screw the left and right sides together with cm-8 \* 16 screws and d flat pad.



### Step 3. All screws fixed

After fixing all the screws in step 2, screw the screws into place as shown in the figure below.

